

# IIA project – Q&A and Some Extra Knowledge




Prof. Qixiang Cheng, Dr. Chunhui Yao

# Outline

1. Q&A
2. Some Extra Knowledge



# About the Wavelength Dependence / Bandwidth

To evaluate the performance of a coupler across different wavelengths — that is, to study its **bandwidth** — you can define a specific **wavelength span** at the source. Then, under **Global Properties**, set the number of **frequency points** to determine how many wavelengths will be sampled in each simulation run. This will automatically generate a response curve (e.g., coupling efficiency vs. wavelength).



# How to Use the Mode Expansion Monitor

Mode expansion monitor allow you to analyze the **fraction of power transmitted into any mode(s)** of a waveguide.





1. Add this mode expansion monitor with the Field/Power monitor
2. Select the target mode for expansion (e.g. TE<sub>0</sub> mode)
3. Check with the T<sub>net</sub> (i.e. the fraction of TE<sub>0</sub> mode)

<https://optics.ansys.com/hc/en-us/articles/360034902433-Using-and-understanding-Mode-Expansion-Monitors>

# How to Use the Mode Expansion Monitor

Mode expansion monitor allow you to analyze the **fraction of power transmitted into any mode(s)** of a waveguide.



1. Alien this mode expansion monitor with the Field/Power monitor
2. Select the target mode for expansion (e.g. TE0 mode)
3. Check with the T\_net (i.e. the fraction of TE0 mode)

<https://optics.ansys.com/hc/en-us/articles/360034902433-Using-and-understanding-Mode-Expansion-Monitors>



# Coupling between asymmetrical waveguides

## Mode Effective Index

$$\begin{cases} \frac{dA_0(z)}{dz} = -i\beta A_0(z) - i\kappa A_1(z) \\ \frac{dA_1(z)}{dz} = -i\beta A_1(z) - i\kappa A_0(z) \end{cases}$$

where  $\beta$  is the propagation constant,  $\beta = kn_{\text{eff}} = \omega n_{\text{eff}}/c$

*Effective refractive index experienced by the guided mode*



*Varies over Mode Order, Waveguide geometry, Wavelength, etc...*








# Coupling Between Asymmetrical Waveguides

The key to designing an asymmetrical directional couplers is to **identify matching effective indices** across different modes — i.e., to find the waveguide widths *where different mode orders have approximately the same effective index*.

In Lumerical, you can use the **mode solver** embedded in the **source** or the **mode expansion monitor**:




# Application Scenario of Directional Couplers – MZI


**Directional couplers (DCs)** fundamentally **split and combine light**. This simple function makes them key elements in building everything from diverse waveguide components to large-scale photonic integrated circuits.

A typical example is **Mach-Zehnder Interferometer (MZI)**:


*Michelson interferometer (free-space optics):*



*Integrated MZI with 50:50 DCs and phase shifters:*



*Transmission features:*






# Application Scenario of Directional Couplers – MZI


MZI structures that can be used to create:

1. **Filters:** by exploiting wavelength-dependent interference
2. **Modulators:** by inserting phase shifters (e.g., based on thermo-optic or electro-optic effects) for high-speed modulation
3. **Switches:** by tuning the cross/bar condition of each MZI stage to reconfigure the entire switch network's connectivity
4. **Programmable circuits** for optical computing and sensing applications


*LiNbO<sub>3</sub> MZI modulator:*



*T-O/E-O MZI switches:*




*Programmable MZI network for optical computing:*



# Application Scenario of Directional Couplers – MRR

Imagine looping the split light back onto itself, allowing it to interfere with itself — we got **Micro-ring Resonator (MRR)**



Typical Applications of MRRs include:

1. **Add/drop filters** for WDM systems
2. **Compact modulators** and switches
3. **Nonlinear optics** and **biosensors**
4. **Quantum photonic circuits**

